
Montagehinweise für Q-TECH Zündleitungssätze BMW K Modelle

Unsere Zündleitungssätze enthalten wasserdichte Zündkerzenstecker aus Silikon. Diese Kerzenstecker können nach längerer Betriebszeit sehr fest auf den Zündkerzen sitzen. Verwenden Sie zur Demontage unseren beigelegten Abziehbügel wie gezeigt. Als Alternative bietet es sich an, ein dünnes Seil wie gezeigt zu verwenden. Mit dem Seil lassen sich höhere Auszugskräfte realisieren. Beachten Sie, das Silikonzündkerzenstecker immer vor der Montage gereinigt, und dann mit Zündkerzensteckerfett dünn geschmiert werden müssen.

Our ignition cable sets contain waterproof spark plug connectors made of silicone. These spark plug connectors can sit very tightly on the spark plugs after a long period of operation. To remove them, use our included puller as shown. Alternatively, you can use a thin rope as shown. The rope allows for higher extraction forces. Please note that silicone spark plug connectors must always be cleaned before installation and then lightly lubricated with spark plug connector grease.

