


Q-TECH Falscheider Str.9 D 32584 Löhne Tel. 0 57 32 / 89 17 20
www.q-tech.de e-mail: info@q-tech.de



Gebrauchsanleitung für Halltest Artikel Nr. 130

1. Zündung ausschalten, Tank abnehmen
2. 7-Polstecker aus Steuergerät nach entfernen der Sicherungsspanne ziehen
3. Halltest einstecken und Zündung einschalten
4. Der Wechsel der roten Lampe von AN-AUS oder AUS-AN (je nach Drehrichtung) zeigt den Zündzeitpunkt an. In der Regel ist das die „ S „-Markierung auf dem Schwungrad.
5. Nach den Einstellarbeiten 7-Polstecker wieder richtig aufstecken und mit Spanne verrasten.
6. Bitte beachten Sie, daß bei Arbeiten an Zündanlagen wegen der sehr hohen Spannungen besondere Vorsichtsmaßnahmen gelten. Bei Problemen deshalb immer in die Fachwerkstatt !!!



Q-TECH Falscheider Str.9 D 32584 Löhne Tel. 0 57 32 / 89 17 20
www.q-tech.de e-mail: info@q-tech.de

Operating Instructions:

1. Instructions for Halltest Part Nr. 130

2. Turn off the ignition
3. Disconnect the ICU
4. Connect the Halltest to the factory harness ICU connector and turn on the ignition.
5. Rotate the engine in running direction until the red LED lights up. This is the point of ignition.
6. Remove the Halltest and reconnect the ICU to the factory harness.